




Vertical Pendant Mount Installation Instructions




Side/ Cement Ceiling



Top/ Suspended Ceiling



Materials List



LITESTRAND™



Installation
Instructions




Rubber
Plug Screws



PC tube



Countersunk
Screw



Two In One
Wire Rope

Installation Tools List



Phillips
Screwdriver




Slotted
Screwdriver




Scissors



Pencil










Tape measure











Electric screwdriver (head is $\varnothing 6.0\text{mm}$)

Vertical Pendant Mount Installation Instructions




Vertical Pendant Mount Installation Instructions




Vertical Pendant Mount Installation Instructions

16a Cement ceiling side outlet




16b Ceiling straight outlet



17



18



19

