

## Installation Instructions





#### PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION


- To prevent personal injury or product damage only licensed electricians should install.
- To avoid electric shock or component damage, disconnect power before attempting installation or servicing.
- This product must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local electric codes and safety standards.
- Disconnect product and allow cooling prior to servicing.
- Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
- To prevent product malfunction and/or electrical shock this product must be properly grounded.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- RISK OF CUTS: Some metal parts in the fixture may have sharp edges. To prevent cuts or scrapes, wear gloves when handling parts.
- Properly dispose of packing material and small parts, as these may be hazardous to children.


### **Product Specification**


Size	Wattage (W)	Voltage (V)	Rated Input Frequency (Hz)	Dimension (DxH)
5 in.	6W	AC120V	60Hz	ø5.3x0.5in
7 in.	12W			ø7.1x0.5in
9 in.	18W			ø8.9x0.5in
12 in.	24W			ø11.8x0.5in

### **Retrofit Installation**


## **Friction Clip**








Torsion Clip








5/6" Can


③ Press the friction blade/torsion clip to insert lamp into the recessed housing and restore power.


 Remove trim and existing lamp from recessed fixture.

Screw E26 socket adapter into socket in the recessed housing.


## **Surface Mounting Installation**







2 Connect wires.



3 Place lamp body on to bracket and lock in place with locking pins.

### **Caution**

- 1. WARNING: Risk of fire. Use AC120V 60Hz circuits.
- 2. Suitable for damp locations. Throughly review enclosed installation instructions before installing lighting fixture. A licensed electrician should install product. All electical connections must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local electric codes and safety standards. Reliable operating temperature is -4~104 degree Fahrenheit.
- 3. Please obey fire prevention regulation, do not cover the fixture with any heat insulated materials.
- 4. No serviceable parts.

# **Warranty:**

3

36,000 hours warranty



This product is for indoor use only



For use with dimmers