ThinTek™ Wafer S

Installation Instructions





PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION


- To prevent personal injury or product damage only licensed electricians should attempt to install
- To avoid electric shock or component damage disconnect power before attempting installation or servicing.
- This product must be installed in accordance with the current National Electric Code (NEC) and all applicable federal, state and local electric codes and safety standards.
- Disconnect product and allow cooling prior to servicing.
- Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
- To prevent product malfunction and/or electrical shock this product must be properly grounded.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- The recessed luminaire is intended for mounting only in a covered dry, damp, wet locations.

Instructions:

- 1. Make sure that Power is TURNED OFF at the source to the recessed housing in which you are installing the fixture.
- 2. If a new hole is needed (Fig.1), use a hole cutter to make hole according to the size in the table (Fig.A). A template is provide to assist with laying out the hold locations.
- 3. Connect wire to the power source (Fig.2) (Black to hot, white to neutral, green to ground) [See wiring diagram. Close the J-box securely.
- 4. Adjust the color temperature to the desired setting by sliding the selector switch (Fig.2A). Ensure that the switch is not between positions.
- 5. Select desired color temperature on remote driver box. Fig.A
- 6. Place remote driver box through the cut-out hole and secure driver box with screws (not included).
- 8. Push the spring clips on the fixture up and insert light fixture through the ceiling cut out. Ensure the spring clips are holding the fixture securely. (Fig. 3)
- 9. Restore the power at the source and the installation is completed.










Fig.A

Model	Cut Hole Dimension
TWSF-0306-C-S	2.76" x 2.76"
TWSF-0412-C-S	4.13" x 4.13"
TWSF-0615-C-S	6.10" x 6.10"
TWSF-0820-C-S	8.27" x 8.27"
TWSF-1224-C-S	11.22" x 11.22"

Wiring Diagram:

LINE	BLACK
COMMON	WHITE
GROUND	GREEN